



FUTURA DOOR FURNITURE FITTING INSTRUCTIONS

Fitting Instructions for Codes: 9036, 9037, 9038, 9040, 9041 & 9042.
Suitable for door thicknesses to 55mm.

These handles are designed to be fixed to door with through-fixing bolts and wood screws provided.

Latch

1. Measure the door thickness and mark the centre at desired height for latch.
2. Mark the face of door each side for drilling of spindle and screw holes.
Note: The spindle hole will need to be centred at 60mm from the door edge (backset)
3. Drill a 25mm (1") hole through door edge.
Note: It is important to drill this hole square.
4. Drill a 25mm (1") spindle hole through door face.
Note: For clean cut-outs, drill from both sides, meeting in the middle of door.
Drill 6.0mm holes for through bolts at horizontal position.
5. Remove any loose sawdust and insert latch. Scribe around face, remove, then chisel out recess to enable latch to sit flush with door edge.
6. Insert latch and fasten with screws supplied.
7. Gently close door against frame and mark latch position for fitting of strike plate. Router or chisel so plate fits flush, allowing for plastic recess box if required.

Handles

1. With latch fitted to door, ensure all holes line up prior to fitting door handles.
2. Remove rose covers from levers.
3. Unthread short screws from threaded sleeves. Insert short-end thru-screws through the two horizontal holes in the rose and tighten to threaded sleeve.
4. Insert spindle so an even amount protrudes each side of door.
Note: Grooved side of spindle must be aligned with grub screws on levers.
5. Remove long thru-screws. Insert handle from 'step 3' onto spindle.
6. Insert long thru-screws through other half of handle set and slide over spindle. Tighten screws securely.
7. In the top hole on the mounting plate, secure a wood screw. Then press on rose covers and tighten grubscrew on underside of cover plate for a concealed fix.
8. Tighten the grubscrew on side of levers onto spindle each side of the door.
Note: The grubscrews may need a re-tighten after a bedding-in period. We Recommend Medium Strength Thread-lock to be used, Windsor Code: 1276.
9. Test door and if necessary, adjust strike tongue to take up any rattle.
Note: Take extra care when working through step 2 of the instructions above when establishing the height & position of handles on the door, be sure to mark out both sides of the door the same to ensure the handles are even on both sides.
Note: For clean cut-outs drill from both sides, meeting in the middle of door. Drill 6.0mm (or 1/4") holes for through door bolts.

DUMMY FIXING MOUNT – FUTURA ELITE DOOR FURNITURE

Code 1152 – 8mm Spindle

Zanda 1152 8mm dummy fix mounts are designed to be recessed and screwed onto the door face, with the handle slipping over the top. The handle base plate is then screwed to or bolted through the door.

Note: *It is important to ensure solid fixing is available for handle and dummy mount screws (especially on hollow core doors).*

Fitting Instructions:

1. Test dummy spindle on handle to ensure it fits.
2. Establish height and position for handle on door.
3. Drill a 32mm diameter recess on the face of door to a depth of 4mm.
4. Fit the dummy spindle by drilling and fitting the three wood screws.
Note: *Grooved side of spindle must be aligned with grub screws on levers.*
5. Install the handle onto the spindle ensuring that it sits squarely on the doors face.
6. Attach the handle by screwing the base plate to the door. In some cases where through door bolts are provided, the door can be drilled both sides to accept the through screws.
7. Press on conceal fix rose to base plate and tighten grubscrew on underside.
8. Tighten the grubscrew onto dummy spindle.

Note: *The grub screw may need a re-tighten after bedding-in period. We Recommend Medium Strength Thread-lock to be used.*

Windsor Code: 1276.

Note: No warranty on Futura levers when used as dummies if 1152 Taylor Spindle is not fitted.

Back to Back Dummy Fixing Mount: Code 1152 – 8 mm Spindle

Refer to instructions over page when fitting Dummy Levers back to back (using thru-fixing screws).